

Cometic Gasket Inc Installation Instructions

- *Follow manufacturers recommended torque specifications.
- *Inspect gasket mating surfaces for any damage or defects. Sealing surfaces need to be flat and free of any oils or debris.
- *Gaskets to be installed dry unless otherwise specified.
- *For seals, miscellaneous gaskets and/or spacers please install per OEM specifications.

